

TECHSHEET

webeyeFOG - Matrix

Notes

- (*) High Power consumption.
- (**) In conjunction with wireless webeyeFOG addons.
- (***) In conjunction with wireless webeyeFOG.
- (****) Tamper input.

Matrix

| COMPATABILITY | Wired webeyeFOG | Wireless webeyeFOG | TRX | DOOR CONTACT | KEYFOB |
|--------------------|-----------------|--------------------|-----|--------------|--------|
| Wired webeyeFOG | | | | | |
| Wireless webeyeFOG | | | | | |

| FEATURES | KEY/ALM | IMM/PANIC | TAMPER | FALL OUT | WIRED IN | WIRELESS IN | WIRELESS OUT | ADDON |
|--------------------|---------|-----------|--------|----------|----------|-------------|--------------|-------|
| Wired webeyeFOG | | | | | | | | |
| Wireless webeyeFOG | | | | | | ** | | |
| TRX | | | | | | | *** | |
| DOOR CONTACT | | | **** | | | | *** | |
| KEYFOB | | | | | | | *** | |

| POWER | MAINS | 12V BATTERY | 3.6V BATTERY | BUILT IN BATTERY |
|--------------------|-------|-------------|--------------|------------------|
| Wired webeyeFOG | | | | |
| Wireless webeyeFOG | | | | |
| TRX | | * | | |
| DOOR CONTACT | | | | |
| KEYFOB | | | | |

Terms

- **KEY/ALM**: Enables the webeyeFOG to be armed and activated separately via a wired input. •
- IMM/PANIC: Enables activation of the cannister without arming via wired input. •
- **TAMPER:** Physical tamper buttons that when activated can send a signal to the Fault Output. •
- FAULT OUT: Sends a change of state (NC/NO) when an event occurs e.g. tamper or dead cannister. •
- WIRED IN: The unit can be activated via a wired input.
- WIRELESS IN: The unit can be activated by the wireless webeyeFOG addons.
- WIRELESS OUT: Can send signals to the wireless webeyeFOG via wireless connection.
- ADDON: Requires the wireless webeyeFOG to work, cannot be standalone.